



OAE.045.2/
E0463.S.2
Wireless ctrl 2 Button



WH	→	R
BN	→	H
GN	→	D
YE	→	S no function
GY	→	O no function
Funktion		
BK	→	- Earth
RD	→	+ 12/24V